



### AC input side





DC output side

























#### ■ Features

- Multi-function single unit battery charger or power supply operation modes selectable
- Output voltage and current adjustable via potentiometer
- 3-stage charging curve for charging mode
- -30~+70°C wide operating temperature
- Multiple protections: Short circuit / Over load / Over voltage / Over temperature
- Thermal controlled DC fan for noise reduction
- · Remote ON-OFF control
- · Comply with 62368-1+60335-1/-2-29 dual certification
- · Suitable for lead-acid (Pb) batteries
- Carry handle accessory available (Order NO.:Carry handle, sold separately)
- 3 years warranty

# Applications

- Radio system backup solution
- · Electric scooter charger
- Camping car 

   Buses 

   Heavy duty truck 

   Specialty vehicles
- Surveillance system
- Industrial automation machinery
- Industrial control system
- · Mechanical and electrical equipment


#### **■** GTIN CODE

MW Search: https://www.meanwell.com/serviceGTIN.aspx

#### Description

NPP-1200 is a miniaturized dual-purpose charger and power supply. In addition to being used as a three-stage charger for lead-acid batteries, it can also be used as a constant voltage output power supply to drive general load. The operating mode can be quickly switched by plugging or unplugging a connector on the front panel. Other features include: ultra-wide voltage output, adjustable voltage via VR on the panel (10.5~21V, 21~42V, 42~80V), adjustable charging current (50~100%), built-in intelligent fan with variable speed based on temperature to reduce noise and extend fan lifetime, -30~+70° C wide operating temperature, suitability for use in different environments, built-in remote ON/OFF control, compliance to IEC/EN/UL62368-1 and household EN60335-1/-2-29 dual safety, multiple built-in protections, and 3-year warranty. The NPP-1200 is truly an intelligent, safe, and reliable universal dual-purpose charger and power supply with outstanding cost performance.

# Model Encoding





# **SPECIFICATION for Battery Charger mode (Default)**


MODEL	•	NPP-1200-12	NPP-1200-24	NPP-1200-48		
WODEL	BOOST CHARGE VOLTAGE(Vboost)(default)		28.8V	57.6V		
			27.6V	55.2V		
	FLOAT CHARGE VOLTAGE(Vfloat)(default)					
	VOLTAGE ADJUSTABLE RANGE	10.5 ~ 21V	21 ~ 42V	42 ~ 80V		
		By built-in potentionmeter	Look	1404		
OUTPUT	MAX. OUTPUT CURRENT(CC)		36A	18A		
	CURRENT ADJUSTABLE RANGE	35 ~ 70A	18 ~ 36A	9 ~ 18A		
		By built-in potentionmeter				
	MAX. POWER	1176W	1209.6W	1209.6W		
	RECOMMENDED BATTERY	240 ~ 800AH	120 ~ 420AH	60 ~ 210AH		
	CAPACITY (AMP HOURS) Note.4	90 ~ 264VAC 127 ~ 370VDC				
		47 ~ 63Hz				
	FREQUENCY RANGE	PF>0.98/115VAC, PF>0.95/230VAC at full load				
INPUT	POWER FACTOR (Typ.)  EFFICIENCY (Typ.) Note.6		93%	94%		
	AC CURRENT (Typ.)	12A/115VAC 6.5A/230VAC	33 /6	34 /0		
	INRUSH CURRENT (Typ.)	COLD START 50A at 230VAC				
			iting, charger will shutdown after 5 sec,	re newer on to receiver		
	SHOKT CIRCUIT Note./	21.5 ~ 26V	43 ~ 52V	82 ~ 100V		
PROTECTION	OVER VOLTAGE	· · ·		02 * 100 V		
	OVER TEMPERATURE		off o/p voltage, re-power on to recover omatically after temperature goes down			
		3 stage only	omanoany arter temperature goes down			
	CHARGING STAGE CHARGER OK SIGNAL	, ,	4.5 ~ 5.5V): Charger failure or protection	n status =1 ( -0.5 ~ +0.5V)		
FUNCTION	BATTERY FULL SIGNAL	The TTL signal out, Charger OK = $H(4.5 \sim 5.5V)$ ; Charger failure or protection status = $L(-0.5 \sim +0.5V)$ The TTL signal out, Battery full = $H(4.5 \sim 5.5V)$ ; Charging = $L(-0.5 \sim +0.5V)$				
	REMOTE CONTROL	The TTL signal out, Battery full = H(4.5 ~ 5.5V); Charging = L(-0.5 ~ +0.5V)  Open : Charger stop charging Short : Charger normal work				
	FAN ON/OFF CONTROL	Depends on internal temperature				
	WORKING TEMP.	-30 ~ +70°C (Refer to "Derating Curv	(A")			
	WORKING HUMIDITY	20 ~ 95% RH non-condensing				
ENVIRONMENT						
	TEMP. COEFFICIENT	±0.05%/°C (0 ~ 50°C )				
	VIBRATION	10 ~ 500Hz, 2G 10min./1cycle, 60mir	n each along Y V 7 aves			
	SAFETY STANDARDS			/2-29, UL62368-1, EAC TP TC 004 approved		
	WITHSTAND VOLTAGE	I/P-O/P:3KVAC I/P-FG:2KVAC C	· · · · · · · · · · · · · · · · · · ·	72-29, OLO2300-1, EAC 1F 1C 004 approved		
	ISOLATION RESISTANCE	I/P-O/P, I/P-FG, O/P-FG:100M Ohms				
	ISOLATION RESISTANCE	Parameter	Standard	Test Level / Note		
		Conducted	BS EN/EN55032 (CISPR32)	Class B		
	EMC EMISSION	Radiated	BS EN/EN55032 (CISPR32)	Class A		
	LWG LWISSION	Harmonic Current	BS EN/EN61000-3-2	Class A		
		Voltage Flicker	BS EN/EN61000-3-2			
SAFETY &		Parameter	Standard	Test Level / Note		
EMC (Note 8)		ESD	BS EN/EN61000-4-2	Level 3, 8KV air ; Level 2, 4KV contact		
		Radiated	BS EN/EN61000-4-2	Level 2, 3V/m		
				·		
	EMC IMMUNITY	EFT / Burst	BS EN/EN61000-4-4	Level 2, 1KV		
		Surge	BS EN/EN61000-4-5	Level 3, 1KV/Line-Line,Level 3, 2KV/Line-Ear		
		Conducted	BS EN/EN61000-4-6 BS EN/EN61000-4-8	Level 2, 3Vrms		
		Magnetic Field	BS EIN/EIN0 1000-4-8	, .		
		Voltage Dips and Interruptions	BS EN/EN61000-4-11	>95% dip 0.5 periods, 30% dip 25 period >95% interruptions 250 periods		
	MTBF	625.1K hrs min. Telcordia SR-332	(Bellcore); 63.6K hrs min. MIL-HI	DBK-217F (25°C)		
OTHERS	DIMENSION	250*158*67mm (L*W*H)	(Denicole), 03.0K IIIS IIIIII. MIE-FII	DDIC-2111 (20 €)		
O I I I LINU	PACKING	1.93Kg; 4pcs/ 10Kg / 1.72CUFT				
NOTE	Modification for charger special     All parameters NOT speciall     Float charge voltage(Vfloat)     This is MEAN WELL's suggestions. Derating may be needed unlied the efficiency is measured as	lodification for charger specification may be required for different battery specification. Please contact battery vendor and MEAN WELL for details. If parameters NOT specially mentioned are measured at 230VAC input, rated load and 25°C of ambient temperature. It loads charge voltage(Vfloat) adjustable via potentiomerter in battery charger mode. In his is MEAN WELL's suggested range. Please consult your battery manufacturer for their suggestions about maximum charging current limitation. It loads are erating may be needed under low input voltages. Please check the derating curve for more details. In his efficiency is measured at 16.8V charge voltage(12V model), 33.6V charge voltage(24V model), 67.2V charge voltage(48V model). In his protection mechanism is specified for the case the short circuit occurs after the charger is turned on. In his charger is considered a component which will be installed into a final equipment. All the EMC tests are been executed by mounting the unit on 600mm*900mm metal plate with 1mm of thickness. The final equipment must be re-confirmed that it still meets EMC directives. For guidance on how to be erform these EMC tests, please refer to "EMI testing of component power supplies."  In available on https://www.meanwell.com//Upload/PDF/EMI_statement_en.pdf )  The ambient temperature derating of 3.5°C/1000m with fanless models and of 5°C/1000m with fan models for operating altitude higher than 2000m(6500ft).				



## SPECIFICATION for Power Supply mode (Selectable via pin3 & 4 jumper of 14pins connector on panel)

		, , , , , , , , , , , , , , , , , , , ,				
MODEL		NPP-1200-12	NPP-1200-24	NPP-1200-48		
	DC VOLTAGE	14.4V	28.8V	57.6V		
	VOLTAGE AD HIGTARI E DANGE	10.5 ~ 21V	21 ~ 42V	42 ~ 80V		
	VOLTAGE ADJUSTABLE RANGE	By built-in potentionmeter				
	CURRENT ADJUSTABLE RANGE	35 ~ 70A	18 ~ 36A	9 ~ 18A		
	RATED CURRENT	70A	36A	18A		
	RATED POWER	1176W	1209.6W	1209.6W		
OUTPUT	RIPPLE & NOISE(max.)	180mVp-p	300mVp-p	480mVp-p		
	VOLTAGE TOLERANCE	±1.0%	±1.0%	±1.0%		
	LINE REGULATION	±0.5%	±0.5%	±0.5%		
	LOAD REGULATION	±1.0%	±1.0%	±0.5%		
		1800ms, 60ms/230VAC at full load	± 1.0 /0	-0.070		
	SETUP, RISE TIME	,	Catfullland			
	HOLD UP TIME (Typ.)	16ms/230VAC at 75% load 10ms/230VA	C at full load			
ŀ		90 ~ 264VAC 127 ~ 370VDC				
	FREQUENCY RANGE	47 ~ 63Hz				
INPUT	POWER FACTOR (Typ.)	PF>0.98/115VAC, PF>0.95/230VAC at fu				
	EFFICIENCY (Typ.)	92%	93%	94%		
	AC CURRENT (Typ.)	12A/115VAC 6.5A/230VAC				
	INRUSH CURRENT (Typ.)	COLD START 50A at 230VAC				
	OVERLOAD	105 ~ 115% rated output power				
	O T LINLOAD	Protection type : Constant current limiting,	unit will shutdown after 5 sec, re-power on t	o recover		
PROTECTION	SHORT CIRCUIT	Protection type: Constant current limitin	g, unit will shutdown after 5 sec, re-power	on to recover		
PROTECTION		21.5 ~ 26V	43 ~ 52V	82 ~ 100V		
	OVER VOLTAGE	Protection type: Shut down and latch off	o/p voltage, re-power on to recover			
	OVER TEMPERATURE	Shut down O/P voltage, recovers automatically after temperature goes down				
	REMOTE CONTROL	Open : Power OFF Short : Power Of				
FUNCTION	DC OK	The TTL signal out, DC OK = $H(4.5 \sim 5.5V)$ ; Power supply failure or protection = $L(-0.5 \sim +0.5V)$				
	FAN SPEED CONTROL	Depends on internal temperature	zy, i ewel eapply landle of protection.	0.0 10.01)		
	WORKING TEMP.	-30 ~ +70°C (Refer to "Derating Curve")				
		20 ~ 95% RH non-condensing				
	WORKING HUMIDITY	-40 ~ +85°C, 10 ~ 95% RH non-condensing				
ENVIRONMENT			ng			
	TEMP. COEFFICIENT	±0.05%/°C (0 ~ 50°C)				
	VIBRATION	10 ~ 500Hz, 2G 10min./1cycle, 60min. ea				
	SAFETY STANDARDS	CB IEC62368-1,IEC60335-1/2-29, Dekra BS EN/EN62368-1,BS EN/EN60335-1/2-29, UL62368-1, EAC TP TC 004 approved				
	WITHSTAND VOLTAGE	I/P-O/P:3KVAC I/P-FG:2KVAC O/P-				
	ISOLATION RESISTANCE	I/P-O/P, I/P-FG, O/P-FG:100M Ohms / 50				
		Parameter	Standard	Test Level / Note		
		Conducted	BS EN/EN55032 (CISPR32)	Class B		
	EMC EMISSION	Radiated	BS EN/EN55032 (CISPR32)	Class A		
		Harmonic Current	BS EN/EN61000-3-2	Class A		
CAFETVO		Voltage Flicker	BS EN/EN61000-3-3			
SAFETY &   EMC		Parameter	Standard	Test Level / Note		
(Note 4)		ESD	BS EN/EN61000-4-2	Level 3, 8KV air; Level 2, 4KV contact		
		Radiated	BS EN/EN61000-4-3	Level 2, 3V/m		
	EMO IMMUNITY	EFT / Burst	BS EN/EN61000-4-4	Level 2, 1KV		
	EMC IMMUNITY	Surge	BS EN/EN61000-4-5	Level 3, 1KV/Line-Line,Level 3, 2KV/Line-Ea		
		Conducted	BS EN/EN61000-4-6	Level 2, 3Vrms		
		Magnetic Field	BS EN/EN61000-4-8	Level 1, 1A/m		
		Magnetic Field	B3 EN/EN01000-4-0	· · · · · · · · · · · · · · · · · · ·		
		Voltage Dips and Interruptions	BS EN/EN61000-4-11	>95% dip 0.5 periods, 30% dip 25 period >95% interruptions 250 periods		
	MTBF	625.1K hrs min. Telcordia SR-332 (Be	llcore); 63.6K hrs min. MIL-HDBK-2	· · · · · · · · · · · · · · · · · · ·		
OTHERS	DIMENSION	250*158*67mm (L*W*H)		(20 0)		
DIHEKO	PACKING	1.93Kg; 4pcs/ 10Kg / 1.72CUFT				
NOTE	1. Modification for charger specification may be required for different battery specification. Please contact battery vendor and MEAN WELL for details.  2. All parameters NOT specially mentioned are measured at 230VAC input, rated load and 25°C of ambient temperature.  3. Derating may be needed under low input voltages. Please check the derating curve for more details.  4. The PSU is considered a component which will be installed into a final equipment. All the EMC tests are been executed by mounting the unit on a 600mm*900mm metal plate with 1mm of thickness. The final equipment must be re-confirmed that it still meets EMC directives. For guidance on how to perform these EMC tests, please refer to "EMI testing of component power supplies."  (as available on https://www.meanwell.com//Upload/PDF/EMI_statement_en.pdf)  5. The ambient temperature derating of 3.5°C/1000m with fanless models and of 5°C/1000m with fan models for operating altitude higher than 2000m(6500ft).					







# ■ Function Manual


## 1. Battery Charger or Power Supply Operation modes selectable via pin3 and pin4 jumper

Between pin3 and pin4	Operation modes
Jumper connected	Power supply mode
Jumper removed	Battery charger mode (Default)



## 2. Charging Curve (Charging Mode)


#### © 3 stage charging curve



State	NPP-1200-12	NPP-1200-24	NPP-1200-48
Constant Current	70A	36A	18A
Vboost	14.4V	28.8V	57.6V
Vfloat	13.8V	27.6V	55.2V

O Suitable for lead-acid batteries (flooded, Gel and AGM)





※ V₀ x I₀ must be less than or equal to the rated power. Please refer to derating curve (page 4).

## 3. Charger OK / DC OK Signal

Charger OK / DC OK signal is a TTL level signal.

The maximum sourcing current is 10mA.

Charger OK / DC OK signal	Charger status
"High": 4.5 ~ 5.5V	Work normally
"Low" : -0.5 ~ 0.5V	Failure or protection function activated




#### 4.Remote ON-OFF Control

The NPP-1200 can be turned ON/OFF by using the "Remote Control" function.

Between pin7 remote ON-OFF and pin8 +12Vaux	Charger status
Short ( Pin 7 = 10.8 ~ 13.2V)	ON (Default)
Open ( Pin 7 = -0.5 ~ 0.5V)	OFF



# 1200W High Reliable Ultra Wide Output Range Battery Charger & Power Supply 2-in-1 NPP-1200 series



## $\frak{\%}$ Connector Pin No. Assignment: HRS DF11-14DP-2DS or equivalent

Pin No.	Assignment	Mating Housing	Terminal
1,2,11~14	NC		
3,4	Battery Charger or		
5,4	Power Supply mode selectable		
5	Battery Full	HRS DF11-14DS	HRS DF11-**SC
6	Charger OK (Charger mode) or	or equivalent	or equivalent
	DC OK (Power supply mode)		
7	Remote ON-OFF		
8	+12V-AUX		
9,10	GND-AUX		

### ※ LED Status Table

Charger (Default)		
LED Indicator	Status	
Green Float stage (stage 3) or full charged		
Red Charging (stage 1 or stage 2)		
O No Light	Abnormal	
Power supply mode		
LED Indicator Status		
Green Normal working		
○ No Light Abnormal		



 $\fint M$  Control Pin No. Assignment : HRS DF11-14DP-2DS or equivalent

2	1
14	13

Mating Housing	HRS DF11-14DS or equivalent
Terminal	HRS DF11-**SC or equivalent

Pin No.	Function	Description
1,2,11~14	NC	
3,4	Battery charger / Power supply	Open: Battery charger, Color of LED loading indicator: Reference to battery charger. Short: Power supply, Color of LED loading indicator :Green.
5	Battery Full	Battery Full Signal, referenced to GND-AUX(Pin 9 & 10). The Signal is a TTL level signal. The maximum sourcing current is 10mA and only for output.(Note.2) Low (-0.5 ~ 0.5V): When the battery is charging. High (4.5 ~ 5.5V): When the battery is full.
6	Charger OK / DC OK	Charger OK / DC OK Signal, referenced to GND-AUX(Pin 9 & 10).  The Signal is a TTL level signal. The maximum sourcing current is 10mA and only for output.(Note.2)  Low (-0.5 ~ 0.5V): When the charger fails or the protect function is activating.  High (4.5 ~ 5.5V): When the charger is working properly.
7	Remote ON-OFF	Remote charger ON/OFF Function. The charger can turn the output ON/OFF by dry contact between Remote ON-OFF and +12V-AUX.(Note.2) Short (10.8 ~ 13.2V): Charger ON; Open(-0.5 ~ 0.5V): Charger OFF; The maximum input voltage is 13.2V.
8	+12V-AUX	It is controlled by the Remote ON-OFF control.
9,10	GND-AUX	The signal return is isolated from the output terminal. (+V & -V)

Note 1: Non-isolated signal, referenced to [GND (signal)].

Note2: Isolated signal, referenced to GND-AUX

# ■ Accessory List


 $\divideontimes$  Battery Charger or Power Supply mode of pin 3 and pin 4 mating pin along with NPP-1200 (Standard accessory)

Pin 3 and Pin 4 mating pin	Quantity
1FF1HMJ20-020-95BS or equivalent	1




## 

MW's Order No.	Item		Quantity
Carry Handle	1	Handle	1
	2	Foot pad	4
	3	Screw	2



# 2 Foot pad



# ■ INSTALLATION MANUAL

Please refer to : http://www.meanwell.com/manual.html